



Fitting Sheet 3b - VDJ 1600 Landcruiser Clutch

Important tips when fitting a custom V8 T/D Landcruiser Clutch

- Thoroughly clean block face (and sandwich plate if fitted)
- NPC install the ring gear using a heat shrink method. Care is taken to ensure the ring gear is fitted to the flywheel correctly, but before fitting, please check that the ring gear is seated correctly.
- Fit the flywheel and torque bolts to specifications, apply Loctite sparingly on the threads.
- Torque flywheel bolts to 182nm
- Fit new spigot bearing.
- Clean flywheel face, pressure plate face & inside diameter of pressure plate casting with thinners. Make sure that the inner crank area around the spigot bearing & crank bolts is also cleaned thoroughly.
- Remove clutch fork, check for wear, clean and regrease behind fork and on pivot ball.
- Fit the supplied pivot ball washers
- DO NOT over grease the clutch spline. Remove all excess grease.
- DO NOT touch the surfaces of the clutch plate with dirty hands.
- Fit clutch using correct aligning tool, use new pressure plate bolts supplied, apply Loctite sparingly on the threads and torque to specifications
- **1600nm Kit:** Fit the 8 x 1/4 step dowels to the flywheel. Using the **M8 x 16 SHCS** bolts torque down the pressure plate evenly **BY HAND** to **39nm (M8x16 SHCS)**.
- **Note: Failure to bolt down evenly can result in damaging the pressure plate and cause operation issues.** Now you are ready to fit your transmission.
- Make sure that the transmission is properly supported when fitting.
- Evacuate dirty or contaminated clutch fluid, and use new fluid.
- Install the 11/16 slave cylinder provided in the clutch kit (the slave cylinder bore is down in size from the factory 3/4 slave cylinder.
- Some adjustment may be needed at the clutch pedal under the dash. Be careful not to go too far with the pedal adjustment, if adjusted too far it can result in the release bearing having constant load applied to the pressure plate (the easiest way to check is to get under the car, push the rod back into the slave cylinder and make sure the fork has free play)
- Finally, the clutch must be run in by driving normally for at least 1000km's

NOTES:

- You may be aware of a possible noise when fitting an aftermarket clutch to the VDJ, HDJ & HZJ Landcruiser. This noise may be heard during gear changes or at idle with the clutch disengaged usually around 2,000rpm and higher. This is not a failure of any part and is not causing any damage to the vehicle.
- Now you have your brand-new NPC clutch fitted you will need to give it a chance to bed in before putting it through any hard use. 1000km's of regular day to day driving is recommended. It's the engagement of the clutch that does the bedding in, so ideally lots of gear changes and around town driving.



Pivot Ball Spacing Washers



Washer orientation on Pivot Ball